

## VICTREX® HT™ G45

### ➤ Product Description:

High performance thermoplastic material, unreinforced PolyEtherKetone (PEK), semi crystalline, depth filtered granules for injection moulding, low flow, FDA food contact compliant, colour natural/beige.

### ➤ Typical Application Areas:

Applications for high strength and stiffness as well as good ductility at higher temperatures. Chemically resistant to aggressive environments, suitable for sterilisation for medical and food contact applications.

### ➤ Material Properties

	CONDITIONS	TEST METHOD	UNITS	TYPICAL VALUE
<b>Mechanical Data</b>				
Tensile Strength	Yield, 23°C	ISO 527	MPa	110
Tensile Elongation	Break, 23°C	ISO 527	%	35
Tensile Modulus	23°C	ISO 527	GPa	4.2
Flexural Strength	At 3.5% strain, 23°C	ISO 178	MPa	130
	At yield, 23°C			180
	125°C			105 *
	175°C			32 *
Flexural Modulus	23°C	ISO 178	GPa	4.2
	275°C			16 *
Compressive Strength	23°C	ISO 604	MPa	140 *
	120°C			90 *
	200°C			30 *
Izod Impact Strength	Notched, 23°C	ISO 180/A	kJ m <sup>-2</sup>	7.0
	Unnotched, 23°C	ISO 180/U		n/b
<b>Thermal Data</b>				
Melting Point		ISO 11357	°C	373
Glass Transition (Tg)	Onset	ISO 11357	°C	152
	Midpoint			160
Specific Heat Capacity	23°C	DSC	kJ kg <sup>-1</sup> °C <sup>-1</sup>	2.2
Coefficient of Thermal Expansion	Along flow below Tg	ISO 11359	ppm K <sup>-1</sup>	45 *
	Average below Tg			55 *
	Along flow above Tg			75 *
	Average above Tg			130 *
Heat Deflection Temperature	1.8 MPa	ISO 75-f	°C	163 *
Thermal Conductivity	Along flow, 23°C	ISO 22007-4	W m <sup>-1</sup> K <sup>-1</sup>	0.32
	Average, 23°C			0.29
<b>Flow</b>				
Melt Viscosity	400°C	ISO 11443	Pa.s	350
<b>Miscellaneous</b>				
Density	Crystalline	ISO 1183	g cm <sup>-3</sup>	1.30
Shore D hardness	23°C	ISO 868		85.5
Water Absorption by immersion	Saturation, 23°C	ISO 62-1	%	0.6 *
	Saturation, 100°C			0.75 *

Electrical Properties				
Dielectric Strength	2mm thickness	IEC 60243-1	kV mm <sup>-1</sup>	23 *
Comparative Tracking Index		IEC 60112	V	150 *
Volume Resistivity	23°C	IEC 60093	Ω cm	10 <sup>16</sup> *
	125°C			10 <sup>15</sup> *
	275°C			10 <sup>9</sup> *
Fire Smoke Toxicity				
Glow Wire Test	2mm thickness	IEC 60695-2-12	°C	960 *

\* Result based on similar products

Typical Processing Conditions	
Drying Temperature / Time	150°C / 3h or 120°C / 5h (residual moisture <0.02%)
Temperature settings	390 / 395 / 405 / 410 / 415°C (Nozzle)
Hopper Temperature	Not greater than 100°C
Mould Temperature	200°C - 220°C
Runner	Die / nozzle >3mm, manifold >3.5mm
Gate	>1mm or 0.5 x part thickness

Mould Shrinkage and Spiral Flow					
Spiral Flow	415°C nozzle, 220°C tool	1mm thick section	Victrex	mm	190
Mould Shrinkage	415°C nozzle, 220°C tool	Along flow	ISO 294-4	%	1.0
		Across flow			

#### Important notes:

- Processing conditions quoted in our datasheets are typical of those used in our processing laboratories  
*Data for mould shrinkage should be used for material comparison. Actual mould shrinkage values are highly dependent on part geometry, mould configuration, and processing conditions.*  
*Mould shrinkage differs for along flow and across flow directions. "Along flow" direction is taken as the direction the molten material is travelling when it exits the gate and enters the mould.*  
*Mould shrinkage is expressed as a percent change in dimension of a specimen in relation to mould dimensions.*
- Data are generated in accordance with prevailing national, international and internal standards, and should be used for material comparison.  
 Actual property values are highly dependent on part geometry, mould configuration and processing conditions. Properties may also differ for along flow and across flow directions

Detailed data available on our website [www.victrex.com](http://www.victrex.com) or upon request

#### World Headquarters

Victrex plc, Hillhouse International, Thornton Cleveleys, Lancashire FY5 4QD United Kingdom  
 Tel: + (44) 1253 897700 Fax: + (44) 1253 897701 Email: [victrexplc@victrex.com](mailto:victrexplc@victrex.com)

VICTREX PLC BELIEVES THAT THE INFORMATION CONTAINED IN THIS BROCHURE IS AN ACCURATE DESCRIPTION OF THE TYPICAL CHARACTERISTICS AND/OR USES OF THE PRODUCT OR PRODUCTS, BUT IT IS THE CUSTOMER'S RESPONSIBILITY TO THOROUGHLY TEST THE PRODUCT IN EACH SPECIFIC APPLICATION TO DETERMINE ITS PERFORMANCE, EFFICACY AND SAFETY FOR EACH END-USE PRODUCT, DEVICE OR OTHER APPLICATION. SUGGESTIONS OF USES SHOULD NOT BE TAKEN AS INDUCEMENTS TO INFRINGE ANY PARTICULAR PATENT. THE INFORMATION AND DATA CONTAINED HEREIN ARE BASED ON INFORMATION WE BELIEVE RELIABLE. MENTION OF A PRODUCT IN THIS DOCUMENTATION IS NOT A GUARANTEE OF AVAILABILITY. VICTREX PLC RESERVES THE RIGHT TO MODIFY PRODUCTS, SPECIFICATIONS AND/OR PACKAGING AS PART OF A CONTINUOUS PROGRAM OF PRODUCT DEVELOPMENT. VICTREX® IS A REGISTERED TRADEMARK OF VICTREX MANUFACTURING LIMITED. VICTREX PIPES™ IS A TRADEMARK OF VICTREX MANUFACTURING LIMITED. PEEK-ESD™, HT™, ST™ AND WG™ ARE TRADEMARKS OF VICTREX PLC. VICOTE® AND APTIV® ARE REGISTERED TRADEMARKS OF VICTREX PLC.

VICTREX PLC MAKES NO WARRANTIES, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, A WARRANTY OF FITNESS FOR A PARTICULAR PURPOSE OR OF INTELLECTUAL PROPERTY NON-INFRINGEMENT, INCLUDING, BUT NOT LIMITED TO PATENT NON-INFRINGEMENT, WHICH ARE EXPRESSLY DISCLAIMED, WHETHER EXPRESS OR IMPLIED, IN FACT OR BY LAW. FURTHER, VICTREX PLC MAKES NO WARRANTY TO YOUR CUSTOMERS OR AGENTS, AND HAS NOT AUTHORIZED ANYONE TO MAKE ANY REPRESENTATION OR WARRANTY OTHER THAN AS PROVIDED ABOVE. VICTREX PLC SHALL IN NO EVENT BE LIABLE FOR ANY GENERAL, INDIRECT, SPECIAL, CONSEQUENTIAL, PUNITIVE, INCIDENTAL OR SIMILAR DAMAGES, INCLUDING WITHOUT LIMITATION, DAMAGES FOR HARM TO BUSINESS, LOST PROFITS OR LOST SAVINGS, EVEN IF VICTREX HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES, REGARDLESS OF THE FORM OF ACTION.